

Slide 2: (add) Save round cardboard to use as drill surface for rear cell cover, OTA cover and eyepiece cap.

Slide 8: (changed) Use Loctite 425 on the barrel and eyecup threads; Loctite contact gel on the rubber eyecup, 5 spots

Slide 9: (changed) Use Loctite 425 on eyepiece ring. 425 is for plastic to metal surfaces

USE GLUE SPARINGLY

Preparing Telescope

Unpack Telescope

Remove Telescope, with bag, from foam.. Return foam and bag to box.

Plastic bag will be reused to transport, with foam, in original shipping box.

Save the Round Cardboard for base when drilling rear cell, front cover and eyepiece cap.



The bag keeps the foam from sticking to the base. Nasty stuff to remove. The round cardboard can be used to hold cell screws and as a drilling surface for three cell holes, OTA cap and EP cap.



Make sure feet are well attached. We've lost some in the past when they were just inserted and not glued in.

Occasionally, a base needs to be separated and the bushing staples need to be driven deeper, to keep from rubbing/scratching the base. You'll know when to do this.



Accessory bars make great tool hangers in the workshop.



Use the screwdriver to poke three holes in the "round" cardboard for the three screws.

If you're modifying more than one, use the "round" from each scope.

Rear Cell (Mirror)

Remove three screws to free rear cell. Remove Cell from OTA. Remove adjusting hardware used for collimating. Place mirror assembly face down on a clean rag...screws facing up. (Use existing screws) Ensure existing screws are tight on the cell. (remove springs, turn snugly, CCW, with needle-nose pliers, replace springs)

Use new hardware (3 washers and 3 locknuts, 5mm threads). Align screws in smaller holes, (drill out to 15/64") attach washer and locknuts onto protruding threads and tighten flush with locknuts (ensure free movement)

Reinstall cell. Set OTA aside for Collimating

IMAGES FOLLOW...When turning the screws CCW, remove the springs and grasp the screw as close to the cover as possible...to avoid crimping the threads where the locknuts screw on.



Remove all six pieces of hardware on rear of cell and remove the black round paper from rear of mirror.

Drill existing small holes to 15/64" holes and make sure they align with the three screws for full range of motion, up and down on the springs without side pressure. Check tightness of screws, (remove springs, (temporarily), turn screws with needle-nose pliers, CCW, for tightness).

(Use the round packing cardboard as a base for holding cell screws and for drilling cell cover, tube cover and eyepiece cap.)

Press down on rear cover to attach washers and screws...hand tighten.

Use socket wrench to tighten locknuts until screw is flush with top of nut and re-insert cell into rear of the tube. Set OTA aside for collimating.



USE GLUE SPARINGLY...VERY IMPORTANT


Give time to dry. Rotate the Zoom eyepiece from end to end to ensure the glue did not lock the main body.

Contact gel on base of rubber eyecup in five spots to hold in place. (apply just a small drop of the super glue gel)



After removing ring from focuser, apply 425 Loctite to the ring threads sparingly.

Leave focuser extended. Rethread the focus ring and let dry before inserting hex-head screws and using collimator.



Zoom eyepiece may be an Orion, 7mm to 21mm...or...a Celestron, 8mm to 24mm. (2018)



The mount in this image is slightly different...actual mount has open rails and no back "tab" hanging down, and two holes to mount on the screws on top of the Optical Tube.



Cut strips of heavy duty, double sided tape, (3M, black, is good and I just cut the width of the spool), and place them on the mount "rails", centered with the screw holes. (they don't need to go "end-to-end")

Check the Alt/AZ adjustment screws and center them through their range of motion. (you can tell)

EZ Finder II

Check the Alt/AZ adjustment screws and center them through their range of motion. (you can tell)

Mounting and Alignment of EZ Finder. (1) Center a distant object in the EP and Zoom-in to 8mm, maintain object in center. (2) Remove the red paper from the tape on the rails. (3) Switch on the Red LED, using the on/off switch.

- (4) With object still centered, place the EZ Finder mount, over the screws on the OTA and onto the tube while keeping the red dot as close to the centered object as possible, centered vertically, and press it down onto the tube.
- (5) Thread the holding nuts onto the screws and tighten them on the mount, to the tube. Keep alignment as close as possible, by checking alignment as you tighten the nuts onto the base and holding the finder in position. (It helps to have three hands :<))
- (6) Check for centered object in EP and adjust Alt/AZ controls to "place" red dot on object that is centered in the EP. (should be minimal)

Mounting and Alignment of EZ Finder. (1) Center a distant object in the EP and Zoom-in to 8mm, maintain object in center. (2) Remove the red paper from the tape on the rails. (3) Switch on the Red LED, using the on/off switch. (4) With object still centered, place the EZ Finder mount, over the screws on the OTA and onto the tube while keeping the red dot as close to the centered object as possible, centered vertically, and press it down onto the tube. (5) thread the holding nuts onto the screws and tighten them on the mount, to the tube. Keep alignment as close as possible, by checking alignment as you tighten the nuts onto the base and holding the finder in position. (It helps to have three hands :<))

(6) Check for centered object in EP and adjust Alt/AZ controls to "place" red dot on object that is centered in the EP. (should be minimal)

